

Solar Plus ventilation - Rekt.



<p>SKR - Kanal</p> <p>Bestillingskode: SKR-a-b-L-s /s_z</p>	<p>STR - T-stykke</p> <p>Bestillingskode: STR-a1-a2-a3-b-s1/s2/s3-L1-L2-L3-r</p>	<p>SBSR - S-slag</p> <p>Bestillingskode: SBSR-a1-b-a2-S-L-s /s_z</p>	<p>SAR - Afgrening</p> <p>Bestillingskode: SAR-a-b-s a = a+100</p>	<p>SPSR - Afgrening</p> <p>Bestillingskode: SPSR-a-b-Ød-h-s h = 100</p>																	
<p>SORU - Overgangsstykke</p> <p>Set fra rund ende (Ød) - Negative mål, ex. e = -50 angiver at e ligger udenfor a - mål Bestillingskode: SORU-a-b-Ød-L-type-e-h-s e og h angives kun ved type 6</p> <table border="1"> <thead> <tr> <th>a - b (største side) [mm]</th> <th>L [mm]</th> </tr> </thead> <tbody> <tr> <td>100 - 350</td> <td>300</td> </tr> <tr> <td>351 - 750</td> <td>450</td> </tr> <tr> <td>751 - 1200</td> <td>600</td> </tr> </tbody> </table>		a - b (største side) [mm]	L [mm]	100 - 350	300	351 - 750	450	751 - 1200	600	<p>SSR - Spidsstykke</p> <p>Set fra lille ende (Ød) - Negative mål, ex. e = -50 angiver at e ligger udenfor a - mål Bestillingskode: SSR-a-b-c-d-L-type-e-h-s /s_z e og h angives kun ved type 6</p> <table border="1"> <thead> <tr> <th>a - b (største side) [mm]</th> <th>L [mm]</th> </tr> </thead> <tbody> <tr> <td>100 - 350</td> <td>300</td> </tr> <tr> <td>351 - 750</td> <td>450</td> </tr> <tr> <td>751 - 1200</td> <td>600</td> </tr> </tbody> </table>		a - b (største side) [mm]	L [mm]	100 - 350	300	351 - 750	450	751 - 1200	600	<p>SBXR - Afrundet bøjning</p> <p>Bestillingskode: SBXR-a1-b-a2-GR-r-s /s_z-L1-L2</p>	<p>SBR - Skarpkantet bøjning</p> <p>Bestillingskode: SBR-a1-b-a2-GR-r-s1/s2-L1-L2</p>
a - b (største side) [mm]	L [mm]																				
100 - 350	300																				
351 - 750	450																				
751 - 1200	600																				
a - b (største side) [mm]	L [mm]																				
100 - 350	300																				
351 - 750	450																				
751 - 1200	600																				

Kompetencecenter Nord
 Hellebården 1
 9230 Svenstrup J
 Tlf.: VVS: 96 34 27 00
 Tlf.: EL: 96 34 22 00

Kompetencecenter Syd
 Industrivej Vest 43
 6600 Vejlen
 Tlf.: VVS: 76 96 20 30
 Tlf.: EL: 76 96 26 00

Kompetencecenter Øst
 Gammelager 14
 2605 Brøndby
 Tlf.: VVS: 43 20 79 00
 Tlf.: EL: 70 24 64 00

